

## LINEAR POSITION SENSOR

Type LPS 4.0 14 IO



worldwide • Weltweit • worldwide



## Content

Declaration of incorporation	4
General safety instructions	5
Technical data	6
Signal output	7
Mounting	9
IO-Link Process structure and parameters	11
Maintenance	20
Toubleshooting	21
Accessories	22
Typeplate	23
Warranty	25
Confirmation of receipt of the manual	27



# INSTRUCTION MANUAL

## Linear Position Sensor

### Type LPS 4.0 14 IO

with analog interface 0..10V and IO-Link Interface  
Measuring range 0..14mm

**Thank you for purchasing an Original-SMW-AUTOBLOK Linear Position Sensor LPS 4.0.**

This **instruction manual** contains the installation, the use and the maintenance instructions of the „LPS 4.0“.

**SMW-AUTOBLOK** reserves the right to make **changes without notice**.

This **instruction manual** is a **part of the „LPS 4.0“** and must be passed to the new owner in case of sale.

This **instruction manual** **may not be** -in whole or in part- **copied** without our written agreement.



Please read the instruction manual carefully before installation and use and always follow the regulations.

Please note especially the sections which are marked with the following signs:



- Danger of injury or danger to life if instructions are not followed.
- Danger of damage to the sensor, the machine or the components.

## Declaration of incorporation for a partly completed machinery to machine directive 2006/42/EC

---

The manufacturer: SMW-Autoblok Spannsysteme GmbH  
Wiesentalstraße 28  
88074 Meckenbeuren  
Deutschland / Germany  
Tel.: +49 (0) 7542 - 405 0

herby declares, that the following product:

Product description: Linear Position Sensor  
Type: LPS 4.0 14 IO  
Ident-No.: 208106

Due to its concept and design as it is introduced into the market is according to the following general safety and health EU regulations.










Machine directive: 2006/42/EC  
EMI directive: 2004/108/EC


Applied harmonized norms:

Emission: EN 61000-6-3  
Immunity: EN 61000-6-2

Date: 20.06.2018

  
\_\_\_\_\_  
Signature of responsible person

-  **1. Intended use**  
The linear positioning sensor is exclusively intended to be used as a parts of a production machine. The sensor must only be installed and operated by personal authorized and advised by the operation, that is qualified according to the valid national laws and according to the national and international regulations. Any other use is a non authorized use, and can cause hazards to health and life of persons as well as damage to material.
- The sensor must only be used in perfect functioning condition. The advises of this manual must always be observed.
- For any other use than the intended use or any other use than authorised by the manufacturer the operator is sole and fully responsible. Any changes carried out at the sensor must be authorised by the manufacturer and must be documented properly.
- In addition to this manual all laws, norms and regulations must be observed.
-  **2. Safety requirements**  
In order to protect the unit against fire, electric shock or potential destruction of the electronic components, it must never be exposed to rain or extreme humidity. Direct sun or heat are to be avoided as well.
-  **3. Calibration, recalibration**  
The linear positioning sensor is adjusted and calibrated at the factory for the measuring path specified.
- If the linear positioning sensor is not used as an absolute measuring system, recalibration is not necessary.
- If you are in doubt, please contact the manufacturer.
- A recalibration can only be carried out in the factory.
-  **4. Warranty and avoiding of harms**  
This manual is the basis for installation, use and operation of the linear positioning sensor.
- Before using the linear positioning sensor read the manual carefully. This manual must remain stored at the machine where the linear position sensor installed.
- All operations described in this manual must only be carried out by capable personal authorized by the operation.
-  **5. Safety**  
Always follow the regulations concerning safe working, protection clothes and any other protection devices to be used at the corresponding production machine.
-  **6. General safety advises**
- All safety advises, national and international regulations to avoid accidents as well as company internal working and operation advises have to be observed.
  - Any conditions causing hazards have to be avoided.
  - Interferences that can cause hazards have to be eliminated immediately.
  - Ignoring the safety instructions can cause hazards to persons, environment and / or can cause damage and will make any warranty void.
  - During installation, the installation and maintenance of the linear positioning sensor all safety regulations of the machine, into which the sensor is installed, must be observed.
  - Prior to any runoff this manual must read, and all safety advises must be followed.
  - The manufacturer refuses any claims for problems caused by not following this manual.
-  **7. Safety advises for operation**
- When using the linear positioning sensor in safety relevant operations, precautions must be taken to avoid danger for personal and machine, in case of failure of the sensor. This can be done by posting safety advises on the machine or by adding safety advises to the manual of the machine. Additionally the machine maker can add suitable (mechanical) protections , to avoid any hazards. We also refer to the trouble shooting.
  - The installation and run off must be carried out by qualified personal. All safety regulations for electronic installations must be observed.
  - The sensor must not be opened at all!
  - Before use all connections must be double checked carefully.
  - Never touch the sensing surface (opposed to the plug) with sharp or tipped articles. Use a soft tissue only.
-  Insufficient or improper maintenance makes any warranty from SMW-AUTOBLOK void.
-  **In case of problems or questions please contact SMW-AUTOBLOK directly or one of our authorized offices.**




	LPS 4.0 14 IO
Power supply	24VDC $\pm 10\%$ @ 35mA typ. Inverse-polarity and overvoltage protection
Interface	0...10V, short-circuit-proof, oad > 2 kOhm, IO Link 1.0
Function monitoring	on error: output 0V
Resolution	ca. 5 mV
Reproducibility	$\pm 0,05$ mm
Linearity	$\pm 0,2$ mm
Temperature drift	$\pm 0,25$ mm through the whole operating, temperature range, temperature engaged
Measuring frequency	33 Hz
EMV Compatibility	EN61000-6-2 Immunity / EN61000-6-4 Emission
Power-on phase	The first measuring value is available after 3 sec. approximately
Case dimensions	L x W x H; 35 x 35 x 30,5 mm
Case material	Plastic/Metal
Case protection class	IP 67
Mounting	via threaded holes for M4 screws
Operation and storing temperature ranges	0 to 75°C
Connections	4-pin connector M8x1, male

## Dimensioning Cam / Shiftring


Recommended dimensions of Cams / Shiftrings:

Dimensions	Info
Distance A = 1.0 mm $\pm$ 0.25	A = recommended distance (inside and parallel) between the measuring surface and the Shiftring (ring shape)
Width B = 11 mm	B = recommended width of the Cam or Shiftring
Angle $\alpha = 6^\circ$	$\alpha$ = Angle min. $6^\circ$

### Cam



### Shift ring






## Analog interface

The LPS 4.0 with analog signal outputs provides 0...10V, corresponding to 0...14mm. If there is an upper or lower deviation from the measuring range or in case of an error, 0V or 0mA is output.

## Pin assignment, analog

The following pin assignment applies to the 4-pin cable connector M8x1


Pin	Description	Comment	4-pin cable
1	24V DC	+/- 10%	brown
2	Signal out	0..10V	white
3	GND		blue
4	CQ (Data)	must not be used	black




### Pin assignment connectors M8x 1

Pin	Description
1	24V DC
2	Signal output 0-10 V
3	GND
4	C/Q (Data)

## Use only 4-pin shielded cable

 Use only 4-pin shielded cable. GND is used for power supply and signal. Shield connected on one side at the female connector.

## The pin assignment is binding

 The pin assignment is binding. The lead colours of the cable may vary.

### Analog connection

After the module has been assembled, the cable is connected to the PLC control via a shielded connection cable according to the pin assignment. Only 3 of the 4 wires are relevant for the user. The other two must neither be stripped nor used for any other purposes. The shield should be connected all over and possibly on both sides. Differences in the shield ground(s) are to be avoided; if need be, the shield may be connected only on one side. The securing screw of the M8 flanged connector must be tightened moderately.

### Electric power



When connecting the test sensor to power, all safety advises of the machine or of the external unit (see the corresponding manuals) have to be observed.

The connection must only be carried out by qualified personal.

### Do not lay connection cables in parallel to cables!



Do not lay connection cables in parallel to cables which could cause interferences.

### Consider cable crosssection and cable length!



Per ohm copper resistance, about 35mV offset are added to the measuring signal. Cable crosssection and cable length are to be taken into account.



## Mounting LPS 4.0



### Special care must be taken when mounting



Special care must be taken when mounting the sensor module since correct mounting is decisive for the quality of the measurement signal.

### The following procedure is recommended:

- Mount the LPS 4.0 by means of a support (not contained in the delivery package).
- Set the exact distance to the switch ring (ring shape) or cam.
- Take care that the sensor module is in an exact parallel position to and is concentric with the cylinder axis.
- No minimum distance to metal surfaces has to be observed on the sides, the front and the side facing the support; a distance of 10mm must be kept towards the measuring surface opposite the support..



The mounting positions shown above are not admissible and must be avoided under all circumstances.  
LPS 4.0 scale drawing with tolerances

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

## Input data structure

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Position value												0			
AD9	AD8	AD7	AD6	AD5	AD4	AD3	AD2	AD1	AD0	res	res	res	BD3	BD2	BD1

## Function

BD1	Switching signal 1
BD2	Switching signal 2
BD3	Switching signal 3
AD	Position value

## Values

BDn	bool	0	Switched off
		1	Switched on
AD		0...448	Valid position value in 1/32 mm
		1021	Outside of the value range (below the value range)
		1022	Outside of the value range (above the value range)
		1023	No target

## Configuration

BD1 switchpoint logic	Index 0x3D Subindex 1	
	0 (High-Active)	1 (Low-Active)
BD1 - switching signal 1:		
Target outside of the limits	0	1
Target within the limits	1	0

BD2 switchpoint logic	Index 0x3F Subindex 1	
	0 (High-Active)	1 (Low-Active)
BD2 - switching signal 2:		
Target outside of the limits	0	1
Target within the limits	1	0

BD3 switchpoint logic	Index 0x400	
	0 (High-Active)	1 (Low-Active)
BD3 - switching signal 3:		
Target outside of the limits	0	1
Target within the limits	1	0

## IO-Link Communication and ID Parameters

Direct Paramter Page 1 - Index 0x00							
Sub	Address hex	Name	Type	Data type	Attribute	Value	Comment
<b>Communication Control</b>							
1	0x00	Master Command	R/W	uint8	volatile		written by master
2	0x01	Master cycle time	R/W	uint8	volatile		written by master
3	0x02	Min. cycle time	R	uint8	constant	0x17	2.3 ms
4	0x03	Frame Capability	R	uint8	constant	0x01	ISDU support
5	0x04	IO-Link Version ID	R	uint8	constant	0x10	IO-Link version 1.0
6	0x05	Process Data in	R	uint8	constant	0x50	16bit Pdin, SIO support
7	0x06	Process Data out	R	uint8	constant	0x00	n/a
<b>Validation Parameter</b>							
8	0x07	IO-Link Vendor ID1 (MSB)	R	uint8	constant	0x04	SMW Autoblok
9	0x08	IO-Link Vendor ID2 (LSB)	R	uint8	constant	0x46	
10	0x09	Device ID1 (MSB)	R	uint8	constant	0x03	
11	0x0A	Device ID2	R	uint8	constant	0x2C	
12	0x0B	Device ID3 (LSB)	R	uint8	constant	0xEA	not used
13	0x0C	Function ID1 (MSB)	R/W	uint8	static	0x00	
14	0x0D	Function ID2 (LSB)	R/W	uint8	static	0x00	

## IO-Link Standard Parameters

### System Command (Index 0x02)

Value hex	Value dec	Function
0x40	64	Teach Apply
0x41	65	SP1 Single Value Teach
0x42	66	SP2 Single Value Teach
0x4F	79	Teach Cancel
0x82	130	Restore Factory Settings

### Profile ID (Index 0x0D)

Subindex	Value hex	Function
1	0x0001	Smart Sensor Profile supported
2	0x8000	Device Identification
3	0x8001	Binary Data channel
4	0x8002	Process Data Variable
5	0x8004	Teach Channel

### PD input descriptor (Index 0x0E)

Subindex	Value hex	Function
1	0x010300	SetFBool3.0
2	0x020A06	UIntegerT10.6

### Parameters for Identification

Index hex	Index dec	Name	Type	Data type
0x10	16	Vendor Name	R	char [31]
0x11	17	Vendor Text	R	char [max 32]
0x12	18	Product Name	R	char [max 32]
0x13	19	Product ID	R	char [11]
0x14	20	Product Text	R	char [max 32]
0x15	21	Serial Number	R	char [14]
0x16	22	Hardware Revision	R	char [7]

## IO-Link Device Parameter

Note:

The existing indexes for the various sensors differ according to their properties. For example, indexes for parameterizing an analog output are only available for sensors with an analog output.

Index hex	sub	Name	Type	Data type	Value	Default	Unit
<b>Smart Sensor Profile Parameters</b>							
0x3A		Teach-In Channel	R/W	unit8	0...3	0	
0x3B		Teach-In Status	R	unit8			
0x3C		<b>BD1_SPV - Switching signal 1</b>	R/W	record			
	1	SP1- set point value 1	R/W	unit16	0...448	112	1/32mm
	2	SP1- set point value 2	R/W	unit16	0...448	144	1/32mm
0x3D		<b>BD1_SPC - Switching signal 1 configuration</b>	R/W	record			
	1	switchpoint logic	R/W	unit8	0x00 not inverted 0x01 - inverted 0x02 - 0xFF - not allowed	0x00	
	2	switchpoint mode	R/W	unit8	0x00 - inactive 0x01 - single point mode 0x02 - window mode 0x03 - two point mode 0x04 - 0x7F - reserved 0x80 - centered window mode	0x80	
	3	switchpoint hysteresis	R/W	unit16	0: Normal 1: Medium 3: High	1	
0x3E		<b>BD2_SPV - Switching signal 1</b>	R/W	record			
	1	SP1 - set point value 1	R/W	uint16	0...448	224	1/32mm
	2	SP2 - set point value 2	R/W	uint16	0...448	256	1/32mm
0x3F		<b>BD2_SPC - Switching signal 1 configuration</b>	R/W	record			
	1	switchpoint logic	R/W	uint8	0x00 - not inverted 0x01 - inverted 0x02 - 0xFF - not allowed		
	2	switchpoint mode	R/W	uint8	0x00 - inactive 0x01 - single point mode 0x02 - window mode 0x03 - two point mode 0x04 - 0x7F - reserved 0x80 - centered window mode		
	3	switchpoint hysteresis	R/W	uint8	0: Normal 1: Medium 2: High		

Index hex	sub	Name	Type	Data type	Value	Default	Unit
0x4000		<b>BD3_SPV - Switching signal 1</b>	R/W	record			
	1	SP1 - set point value 1	R/W	uint16	0...448	336	1/32mm
	2	SP1 - set point value 1	R/W	uint16	0...448	368	1/32mm
0x4001		<b>BD3_SPC - Switching signal 1 configuration</b>	R/W	record			
	1	switchpoint logic	R/W	uint8	0x00 - not inverted 0x01 - inverted 0x02 - 0xFF - not allowed	0x00	
	2	switchpoint mode	R/W	uint8	0x00 - inactive 0x01 - single point mode 0x02 - window mode 0x03 - two point mode 0x04 - 0x7F - reserved 0x80 - centered window mode	0x80	
	3	switchpoint hysteresis	R/W	uint16	0: Normal 1: Medium 2: High	1	
<b>Device specific operation parameters</b>							
0x40		<b>Centered Window Width</b>	R/W	record			
	1	BD channel 1 width	R/W	uint16	0...448	32	1/32mm
	2	BD channel 2 width	R/W	uint16	0...448	32	1/32mm
	3	BD channel 3 width	R/W	uint16	0...448	32	1/32mm
0x42		<b>AD_SPC - Analog Signal Set Point Value</b>	R/W	record			
	1	SP1 - set point value 1	R/W	uint16	0...448	0	
	2	SP1 - set point value 2	R/W	uint16	0...448	448	
0x43		<b>AD_SPC - Analog Signal Configuration</b>	R/W	record			
	1	Analog Output Mode	R/W	uint8	0x00 - Rising Ramp 0x01 - Falling Ramp	0x00	
	2	Error Value Hysteresis	R/W	uint16	0: Normal 1: Medium 2: High	0	
	3	Error Replacement Value	R/W	uint8	0b0000 0000 - disabled 0bXXXX XXX1 - out-of-range enabled 0bXXXX XX1X - no target enabled	0	

Index hex	8sub9	Name	Type	Data type	Value	Default	Unit
0x5F		Measurement Data Collection	R	record			
	1	Position value	R	uint16	0...448		1/32mm
	2	Signal quality	R	uint8	0x00 - insufficient / no position acquisition possible 0x01 - acceptable 0x02 - good 0x03 - excellent		
	3	BD1 Status	R	uint8	0: inactive 1: active		
	4	BD2 Status	R	uint8	0: inactive 1: active		
	5	BD3 Status	R	uint8	0: inactive 1: active		
<b>Standard operation control</b>							
0x70		<b>Output Configuration</b>	R/W	record			
	1	Output Type Q1	R/W	uint8	0x00 - push-pull 0x01 - low-side 0x02 - high-side		
	2	reserved	R/W	uint8	0x00 - reserved 0x01 - reserved 0x02 - reserved 0x03 - reserved		
	3	reserved	R/W	uint8	0x02 - reserved 0x03 - reserved		
	4	Analog Output Type UI	R/W	uint8	0x00 - reserved 0x01 - reserved 0x02 - reserved 0x03 - U: 0...10V 0x04 - U: 1...5V		
	5	reserved	R/W	uint8	0...200	0	
	6	reserved	R/W	uint8	0...200	200	
	7	Voltage Low Value	R/W	uint8	0...100	0	0.1V
	8	Voltage High Value	R/W	uint8	0...100	100	0.1V



Index hex	8sub9	Name	Type	Data type	Value	Default	Unit
0x74		<b>Event Configuration</b>	R/W	uint8	0b0000 0000 - application events disabled 0bXXXX XXX1 - no target event enabled	0x00	
	1	<b>Locator Indication Control</b>	R/W	uint8	0x00 - normal indication 0x01 - locator indication	0x00	
<b>User information</b>							
0xC0		<b>UT1 - User Tag 1</b>	R/W	uint32	0x00000000... 0xFFFFFFFF	0	
0xC1	1	<b>UT2 - User Tag 2</b>	R/W	uint16	0x0000... 0xFFFF	0	
<b>Special function</b>							
0xE2		<b>Operating Temperature</b>	R	int8			°C
0xE8		<b>Device characteristics</b>	R	record			
	1	Position Range	R	uint16	448		
	2	Resolution	R	uint16	16		1/512mm

Index hex	sub	Name	Type	Data type	Value	Default	Unit
-----------	-----	------	------	-----------	-------	---------	------

## Event Configuration (Data Storage = yes)

0x78	1	No Target (Warning)	R/W	bool	0: Disabled 1: Enabled		
	2	Signalfehler	R/W	bool	0: Disabled 1: Enabled		

## Service Function (Data Storage = no)

0x7F		Indication Setting	R/W	unit8	0: Normal Indication 1: Locator Indication	0	
------	--	--------------------	-----	-------	---	---	--

## Device Access Locks (Data Storage = yes)

0x0C		Data Storage Lock (Bit1)	R/W	bool	0: false (Data Storage activated) 1: true (Data Storage locked)	0	
------	--	--------------------------	-----	------	--	---	--

## Device Status Information (Data Storage = no)

0x24		Device Status	R	unit8	0: Device is OK 2: Out of specification	0	
0x25		Detailed Device Status	R	unit 8 [9]	Active Events, see IOLink 1.1-Specification		

## Operation Information (Data Storage = no)

0xE0		Operating Hours	R	unit32	0: 0x3FFFFFFF Resolution 0,25h		0,25h
------	--	-----------------	---	--------	-----------------------------------	--	-------

## User Specific Information (Data Storage = yes)

0x18		Application Specific Tag	R/W	char [32]	Always a step ahead		
0xC0		User Tag	R/W	char [32]	LPS 4.0 Series		

## Device Characteristics (Data Storage = no)

0xE8	1	Position Range	R	unit16	LPS 4.0 14: 0...960		
	2	Resolution	R	unit16	50 µm		

## Process Data (Data Storage = no)

0x28		Process Data Values	R	unit16	See Process Data Structure		
------	--	---------------------	---	--------	----------------------------	--	--

## Observation (Data Storage = no)

0xEC	1	Measured Value	R	unit16	LPS 4.0 14: 0...960		1/20 mm
	2	Signal Quality	R	unit8	0: Insufficient 1: Acceptable 2: Good 3: Excellent		
	3	Switching Signal 1	R	unit8	0: Inactive 1: Active		
	4	Switching Signal 2	R	unit8	0: Inactive 1: Active		
	5	Switching Signal 3	R	unit8	0: Inactive 1: Active		



Note: At parameter „0xEC“ it is only possible to read the complete parameter. Accessing of subindexes is not possible here.

## Error Codes

In case of a fault, the sensor transmits the error codes detailed in the following table. The error code consists of 2 bytes. The higher value byte, here 0x80, represents the IO-Link device as the emitter. The lower value byte represents the actual fault.

Error	Error code	Comment
Index unavailable	0x8011	R/W access to unavailable parameter index.
Unavailable subindex	0x8012	R/W access to unavailable parameter subindex.
Service temporarily unavailable	0x8020	Write/read access to parameter limited by the device status is not possible.
Access denied	0x8023	Write attempt to read-only address.
Invalid value range, parameter	0x8030	For all R/W parameters outside of the valid value range.
Parameter value too large	0x8031	For all R/W parameters above the valid value range.
Parameter value too small	0x8032	For all R/W parameters beneath the valid value range.

## Event Data

The sensor is capable of transmitting events that occur:

Event	Instance	Type	Mode	Event Qualifier	Event Code	Description
PDU Buffer overflow	DL	Error	Single shot	0x72	0x5200	Size of the transmitted data package can not be processed by the sensor
PDU Checksum error	DL	Error	Single shot	0x72		
PDU Procedure error PDU Flow control error	DL	Error	Single shot	0x72	0x5600	Asynchrony in the transmission of the PDU data
Restricted PDU service	AL	Error	Single shot	0x73	0x5800	Submitted service request is invalid
No damping element	APP	Warning	Appear/ Disappear	0xE4/0xA4	0x8CA4	No damping element or no position determination possible

## Maintenance, service

The LPS 4.0 usually works without maintenance.

Any way the function should be tested in regular intervals when testing the machine tool.

### **The following tests need to be carried out:**

- Check the relative position of the sensor to the cam of the cylinder.
- Check if all mounting bolts are tightened correctly and check the cam of the cylinder.
- Check the switch ring.
- Check that the sensing surface has no physical damage.
- Check that there is no contamination of the sensor.

## LPS 4.0 analog

The LPS 4.0 sensor is factory set, so that the full measuring range results in a proportional signal of 0-10V.

In case the sensor detects a non logical position or is out of its measuring range, it will give a 0 Volt or 0 mA output signal.

As the SPS can not identify if the 0-signal is a 0 mm signal or an error, the sensor should be adjusted mechanically so that the position "0" is out of the mechanical measuring/stroke range of the cam /switch ring of the cylinder.

## Troubleshooting

Fault	Cause	Remedy
No IO-Link connection to device	<b>A</b> The C/Q communication port on the sensor is not connected to the IO-Link master	Make sure that the C/Q communication port is connected to the IO-Link master.
	<b>B</b> No power supply	Check whether there is a reason for the absence of the power supply (installation or maintenance work, etc.). switch on the power supply.
Target does not get detected	<b>A</b> Sensor is too far away from the item to be detected	Check the mounting and, if necessary, adjust the sensor to the correct distance.

## Connecting Cable

Connection cables and matching connectors are not included in the delivery package.


They can be ordered from (special length up to 20m on request).

The wire cross section min. 0.14 mm<sup>2</sup>.

Description (Connecting Cable for LPS 4.0 14)	SMW-ID-No.
<b>Connecting Cable 5m straight</b> 5m Length, 4-pin M8x1 connector, straight	208244
<b>Connecting Cable 5m angled</b> 5m Length, 4-pin M8x1 connector, angled	208247
<b>Connecting Cable 10m straight</b> 10m Length, 4-pin M8x1 connector, straight	208245
<b>Connecting Cable 10m angled</b> 10m Length, 4-pin M8x1 connector, angled	208248
<b>Connecting Cable 15m straight</b> 15m Length, 4-pin M8x1 connector, straight	208246
<b>Connecting Cable 15m angled</b> 15m Length, 4-pin M8x1 connector, angled	208249

## Typeplate/Contact

For questions on the product and place an order, please indicate the type marked on the label of the sensor type specification and part number.



Contact:

### SMW-AUTOBLOK Spannsysteme GmbH

Postfach 1151 • D-88070 Meckenbeuren  
 Wiesentalstraße 28 • D - 88074 Meckenbeuren  
 Tel.: +49 (0) 7542 - 405 - 0

Sales Germany:

Fax: +49 (0) 7542 - 3886  
 E-Mail ► [vertrieb@smw-autoblok.de](mailto:vertrieb@smw-autoblok.de)

Sales International:

Fax: +49 (0) 7542 - 405 - 181  
 E-Mail ► [sales@smw-autoblok.de](mailto:sales@smw-autoblok.de)

[illegible]



# 12 month warranty

**Product: Linear Position Sensor**

SMW-AUTOBLOK guarantees the proper function of the sensor, if use and storage are in accordance with the technical instructions of this manual.

In case the sensor does not perform properly, a repair or exchange is done, after inspecting the circumstances.

In case of a production error the sensor is repaired free of charge within the warranty period.

The warranty period is 12 month.

In order to claim warranty, the sensor must be returned in the original packaging.

The return shipment must be accompanied by a detailed trouble description.

Otherwise the manufacturer reserves the right to void any warranty claims.





# Empfangsbestätigung für die Betriebsanleitung Confirmation of receipt of the instruction manual



Hiermit bestätigt die vom Betreiber/ Anwender beauftragte Person

This certifies the operator assigned by the operating company

Herr / Frau

Mr. / Mrs.

den Erhalt der Betriebsanleitung sowie deren Inhalte, insbesondere das Kapitel Sicherheit gelesen und verstanden zu haben.

hereby confirms to have received the instruction manual and to have read and understood the content, especially the chapters concerning safety.

Bediener

Datum

Operator

Date

Betreiber / Sachbeauftragter

Datum

Operating Company /  
Authorised person

Date



Id.Nr. / Id. No.

:

Artikelbez. / Item

:

Gewicht / Weight

:

Seriennr. / Serialno.

:

Bitte ausgefüllt zurückschicken an:

Please send the filled in form back to:

**SMW-AUTOBLOK**

**Spannsysteme GmbH**

**Wiesentalstraße 28**

**D-88074 Meckenbeuren**

**Fax: +49 (0) 7542 - 405 181**

**Mail: sales@smw-autoblok.de**





Id. No. :


Item :

Weight :

Serialno. :

**Germany**

SMW-AUTOBLOK Spannsysteme GmbH  
Postfach 1151 • D-88070 Meckenbeuren  
Wiesentalstraße 28 • D-88074 Meckenbeuren  
Tel.: +49 (0) 7542 - 405 - 0  
Vertrieb Inland ► [vertrieb@smw-autoblok.de](mailto:vertrieb@smw-autoblok.de)  
Fax: +49 (0) 7542 - 3886  
Sales International ► [sales@smw-autoblok.de](mailto:sales@smw-autoblok.de)  
Fax: +49 (0) 7542 - 405 - 181

**U.S.A.**

SMW-AUTOBLOK Corporation  
285 Egidi Drive - Wheeling, IL 60090  
Tel. +1 847 - 215 - 0591  
Fax +1 847 - 215 - 0594  
E-mail ► [autoblok@smwautoblok.com](mailto:autoblok@smwautoblok.com)

**Japan**

SMW-AUTOBLOK Japan Inc.  
1-56 Hira, Nishi-Ku  
461-Nagoya  
Tel. +81 (0) 52 - 504 - 0203  
Fax +81 (0) 52 - 504 - 0205  
E-mail ► [japan@smwautoblok.co.jp](mailto:japan@smwautoblok.co.jp)

**China**

SMW-AUTOBLOK (Shanghai) Work Holding Co., Ltd.  
Building 6, No.72, JinWen Road, KongGang  
Industrial Zone, ZhuQiao Town, Pudong District  
201323, Shanghai P.R. China  
Tel. +86 21 - 5810 - 6396  
Fax +86 21 - 5810 - 6395  
E-mail ► [china@smwautoblok.cn](mailto:china@smwautoblok.cn)

**Mexico**

SMW-AUTOBLOK Mexico, S.A. de C.V.  
Acceso III No. 16 Int.9,  
Condominio Quadrum  
Industrial Benito Juarez  
Querétaro, Qro. C.P. 76120  
Tel. +52 (442) 209 - 5118  
Fax +52 (442) 209 - 5121  
E-mail ► [smwmex@smwautoblok.mx](mailto:smwmex@smwautoblok.mx)

**India**

SMW-AUTOBLOK Workholding Pvt. Ltd.,  
Plot No. 4, Weikfield Industrial Estate,  
Gat No. 1251, Sanaswadi, Tal - Shirur,  
Dist - Pune. 412 208  
Tel. +91 2137 - 616 974  
Fax +91 2137 - 616 972  
E-mail ► [info@smwautoblok.in](mailto:info@smwautoblok.in)

**Turkey**


SMW AUTOBLOK Makina San, Ve Tic. Ltd. ti.  
Yeni ehir Mah, Osmanli Blv, Volume Kurtkoy Ofis  
No:9, Kat:1, D:4, 32912, Pendik Istanbul  
Tel. +90 216 629 - 2019  
E-mail ► [info@smwautoblok.com.tr](mailto:info@smwautoblok.com.tr)

**Sweden / Norway**

SMW-AUTOBLOK Scandinavia AB  
Kasernvägen 2  
SE - 281 35 Hässleholm  
Tel. +46 (0) 761 420 111  
E-mail ► [info@smw-autoblok.se](mailto:info@smw-autoblok.se)

**Italy**

AUTOBLOK s.p.a.  
Via Duca D'Aosta n.24  
Fraz. Novaretto  
I-10040 Caprie - Torino  
Tel. +39 011 - 9638411  
Tel. +39 011 - 9632020  
Fax +39 011 - 9632288  
E-mail ► [info@smwautoblok.it](mailto:info@smwautoblok.it)

**France**


SMW-AUTOBLOK  
17, Avenue des Frères Montgolfier - Z.I. Mi-Plaine  
F-69680 Chassieu  
Tel. +33 (0) 4 - 727 - 918 18  
Fax +33 (0) 4 - 727 - 918 19  
E-mail ► [autoblok@smwautoblok.fr](mailto:autoblok@smwautoblok.fr)

**Great Britain**

SMW-AUTOBLOK Telbrook Ltd.  
7 Wilford Industrial Estate  
Ruddington Lane, Wilford  
GB-Nottingham, NG11 7EP  
Tel. +44 (0) 115 - 982 1133  
E-mail ► [info@smw-autoblok-telbrook.co.uk](mailto:info@smw-autoblok-telbrook.co.uk)

**Spain**

SMW-AUTOBLOK IBERICA, S.L.  
Ursalto 10 - Nave 2, Pol. 27 - Mateo Gaina  
20014 San Sebastián (Guipúzcoa) (Spain)  
Tel.: +34 943 - 225 079  
Fax: +34 943 - 225 074  
E-mail ► [info@smwautoblok.es](mailto:info@smwautoblok.es)

**Russia**

SMW-AUTOBLOK Russia  
B.Tulskaya str., 10, bld.3, off. 323,  
115191 Moscow (Russia)  
Tel. +7 495 -231-1011  
Fax +7 495 -231-1011  
E-mail ► [info@smw-autoblok.ru](mailto:info@smw-autoblok.ru)

**Taiwan**

AUTOBLOK Company Ltd.  
No.6, Shuyi Rd., South Dist.,  
Taichung, Taiwan  
Tel. +886 4-226 10826  
Fax +886 4-226 12109  
E-mail ► [taiwan@smwautoblok.tw](mailto:taiwan@smwautoblok.tw)

**Czech Republic / Slovakia**

SMW-AUTOBLOK s.r.o.  
Merhautova 20  
CZ - 613 00 Brno  
Tel. +420 513 034 157  
Fax +420 513 034 158  
E-mail ► [info@smw-autoblok.cz](mailto:info@smw-autoblok.cz)

**Poland**

SMW-AUTOBLOK Poland Sp. z o.o.  
Ul Ligocka 103 - Building 8  
40-568 Katowice  
Tel. +48 (0) 664 673 428  
E-mail ► [info@smwautoblok.pl](mailto:info@smwautoblok.pl)

**Korea**

SMW-AUTOBLOK KOREA CO., LTD.  
1108 ho, Baeksang Startower 1st,  
65, Digital-ro 9-gil, Geumcheon-gu  
Seoul, ROK-08511, Korea  
Tel. +82 2 6267 9505  
Fax +82 2 6267 9507  
E-mail ► [info-korea@smw-autoblok.net](mailto:info-korea@smw-autoblok.net)